

# DURACELL® RECHARGEABLE CAMCORDER BATTERIES

## Rechargeable Camcorder Batteries

Duracell Part #	Duracell mAh	Description	Fits Models	Replaces OEM Part #
DR10RES	2100	6 Volt NiMH Camcorder Battery	GE, JVC, Magnavox, Minolta, Nikon, Panasonic, RCA, Sanyo, Sharp, Sony	BN-V12, HHR-V20A
DR11RES	4200	6 Volt NiMH Camcorder Battery	GE, JVC, Magnavox, Minolta, Nikon, Panasonic, RCA, Sanyo, Sharp, Sony	HHR-V40, NP-90
DR5RES	2200	7.2 Volt Li-Ion Camcorder Battery	Sony CCD-TRV120, -TRV620, -TRV900, DCR series, TRV100, 210, 720	NP-F550, NP-F570
DR7RES	2500	3.6 Volt NiMH Camcorder Battery	Sharp VL-A10, A110, AH130, AH150, AH160, E600, E650, E750, E760, E780	BT-H21, BT-H22
DR9523	1100	7.2 Volt Li-Ion Camcorder Battery	Hitachi DZ-MV100, -MV100A, MV100E, MV200; Panasonic PV-DBP8A, GS15, GS12	CGR-D08A/1B
DR9554	950	7.4 Volt Li-Ion Camcorder Battery	JVC GR-D20, -D201, -D230, -D33, -D72, -D94	BN-V408
DR9607	720	7.4 Volt Li-Ion Camcorder Battery	Panasonic PV-GS70, GS120, GS200, VDR-M30, M50, M70	CGA-DU07A/1B
DR9608	1400	7.4 Volt Li-Ion Camcorder Battery	Panasonic PV-GS150, GS19, GS50, GS55, GS70;	CGA-DU12A/1B
DR9609	2000	7.2 Volt Li-Ion Camcorder Battery	Panasonic PV-GS19; Hitachi DZ-BX35A	CGA-DU21A/1B
DR9625	1300	7.4 Volt Li-Ion Camcorder Battery	Canon VIXIA HG10, HV20, HV30, ZR-100, 500, 800	BP-2L12, BP-2L14
DR9652	720	3.7 Volt Li-Ion Camcorder Battery	Sanyo Xacti VPC-C5, E1, E2, DG65, CA9	DB-L20, DB-L20AU
DR9656	700	7.2 Volt Li Ion Camcorder Battery	JVC GR-D275, -D295, -D645, GZ-MG27, MG40, MG70, MG77	BN-VF707
DR9669	750	7.4 Volt Li-Ion Camcorder Battery	Samsung SCD-351, -353, -355, -365, -DC173, -DC575	SB-LSM80
DR9674	1640	7.4 Volt Li-Ion Camcorder Battery	Sony DCR-DVD610, DVD810, HC52, SR45, -SR85, HDR-HC9	NP-FH50, NP-FH60, NP-FH70
DR9682	720	7.4 Volt Li-Ion Camcorder Battery	Samsung HMX-H100, SC-MX10, SC-MX20, SMX-F34	AD43-00180A, IA-BP85ST
DR9687	780	7.4 Volt Li-Ion Camcorder Battery	Samsung SC-D381, D385, DX103, VP-DX100i, DX105i	IA-BP80W
DRC511RES	1400	7.4 Volt Li-Ion Camcorder Battery	Canon Optura 10, 20, ZR10, ZR20, ZR30MC, ZR40, ZR50, ZR60, ZR70MC, ZR80, ZR90, EOS-D series, Powershot G series	BP-511

## Rechargeable Camcorder Battery Chargers

Duracell Part #	Description	Fits Models
DRCHCAMT	DURACELL® Universal Camcorder Battery Charger	Canon, GE, Hitachi, JVC, Kyocera, Minolta, Nikon, Olympus, Panasonic, RCA, Ricoh, Samsung, Sanyo, Sony
DRCHCAM1	DURACELL® Camcorder Battery Charger	Canon, Hitachi, Panasonic, Samsung
DRCACHM2	DURACELL® Camcorder Battery Charger	Samsung

## Digital Camera/Camcorder Memory Cards/Card Readers

Duracell Part #	Description	Fits Models
M-CF4G	Compact Flash 4GB Memory Card	Many popular digital cameras and camcorders (see your user manual for exact details)
M-SD2G	Secure Digital 2GB Memory Card	
M-SD4G	Secure Digital 4GB Memory Card	
M-SDMC1G	Secure Digital Micro 1GB Memory Card with Adapters	
M-SDMC1G	Secure Digital Micro 2GB Memory Card with Adapters	
CR-CSDMMC	SD/MMC Card Reader with USB 2.0	
CR-SDMMCBUN	6 In 1 Card Reader with 4 GB Secure Digital Card	
CR-USB	Multi Function Card Reader with Dual USB Hub	