

DURACELL®

High Performance Batteries for Digital Cameras



Rechargeable Digital Camera Batteries

Duracell Part #	Description	Fits Models	Replaces OEM Part #
DR9568	DURACELL® 3.7 Volt 850mAh Li-Ion Digital Camera Battery	Canon PowerShot S100, S200, S230, S400, S410, S500	NB-1L
DR9570	DURACELL® 7.2 Volt 750mAh Li-Ion Digital Camera Battery	Nikon CoolPix 775, 995, 4300, 4800, 5700, 8700	EN-EL1
DR9576	DURACELL® 2.4 Volt 2100mAh NiMH Digital Camera Battery	Kodak Easyshare C300, CX4200, CX4300, CX6000, DX6300	KAA2HR
DR9581	DURACELL® 7.4 Volt 650mAh Li-Ion Digital Camera Battery	Canon Elura 85, 90, Optura 40, 400, 500, ZR-700, ZR-800, ZR-830	NB-2L, NB-2LH
DR9611	DURACELL® 3.7 Volt 700mAh Li-Ion Digital Camera Battery	Casio Exilim EX-S20, -S60, -M20, -Z3, -Z75	NP-20
DR9613	DURACELL® 3.7 Volt 1050mAh Li-Ion Digital Camera Battery	Olympus Camedia C-5000, C7000. Stylus 300, 400, 410, 800, 810	LI-10B
DR9615	DURACELL® 7.4 Volt 1400mAh Li-Ion Digital Camera Battery	Nikon D100, D50, D70	EN-EL3a
DR9618	DURACELL® 3.7 Volt 650mAh Li-Ion Digital Camera Battery	Fuji Finepix series, Pentax Option series, Sanyo VPC-E1090, VPC-X1200	NP-40
DR9624	DURACELL® 3.7 Volt 750mAh Li-Ion Digital Camera Battery	Canon Digital IXUS series, PowerShot series	NB-3L
DR9662	DURACELL® 3.7 Volt 720mAh Li-Ion Digital Camera Battery	Nikon CoolPix P1, S1, S2 S5, S7c, S50, S51	EN-EL8
DR9664	DURACELL® 3.7 Volt 630mAh Li-Ion Digital Camera Battery	Olympus Camedia D630, Stylus 700, 710, 720SW, 750, 770SW	LI-40B, LI-42B
DR9668	DURACELL® 7.2 Volt 700mAh Li-Ion Digital Camera Battery	Panasonic Lumix DMC-FZ7, -FZ18, -FZ30	CGR-S006A/1B
DR9670	DURACELL® 7.4 Volt 1400mAh Li-Ion Digital Camera Battery	Nikon D70s, D80, D90, D100, D200, D300, D700	EN-EL3e
DR9673	DURACELL® 7.4 Volt 1050mAh Li-Ion Digital Camera Battery	Nikon D40, D40x, D60	EN-EL9
DR9678	DURACELL® 3.7 Volt 650mAh Li-Ion Digital Camera Battery	Sony CyberShot DSC-T2, -T70, -T200, -T300	NP-BD1, NP-FD1
DR9705	DURACELL® 3.7 Volt 780mAh Li-Ion Digital Camera Battery	Canon PowerShot SD790, SD800, SD850, SD880	NB-5L
DR9691	DURACELL® 3.7 Volt 770mAh Li-Ion Digital Camera Battery	Sony Cyber-Shot DSC-S750, DSC-S780, MHS-PM1	NP-BK1
DR9692	DURACELL® 7.4 Volt 950mAh Li-Ion Digital Camera Battery	Canon Rebel XS, EOS-405D, Digital Rebel T1s, XS	LP-E5
DR9695	DURACELL® 7.4 Volt 1400mAh Li-Ion Digital Camera Battery	Sony DSLR-A100, A200, A300, A700, A900	NP-FM500H
DR9708	DURACELL® 3.7 Volt 1300mAh Li-Ion Digital Camera Battery	Kodak EasyShare Z612, Ricoh Caplio R1, R1V, R2, RZ1	KLIC-8000, DB-50
DR9709	DURACELL® 3.7 Volt 1000mAh Li-Ion Digital Camera Battery	Panasonic Lumix FX01, -X8, -FX9, -L1, -LX1	CGA-S005
DR9712	DURACELL® 3.7 Volt 720mAh Li-Ion Digital Camera Battery	Kodak Easyshare M753, M853, M893, V550, V610, V705	KLIC-7001
DR9714	DURACELL® 3.7 Volt 900mAh Li-Ion Digital Camera Battery	Sony CyberShot DSC-H10, -H50, -N1, -T20, -W100, -W200	NP-FG1, NP-BG1
DR9735	DURACELL® 3.7 Volt 700mAh Li-Ion Digital Camera Battery	Pentax Optio P70, Sanyo VPC-CG10	DB-L80
DRC4L	DURACELL® 3.7 Volt 750mAh Li-Ion Digital Camera Battery	Canon PowerShot SD300, SD400, SD430, SD450	NB-4L
DRF60RES	DURACELL® 3.7 Volt 1100mAh Li-Ion Digital Camera Battery	Kodak Easyshare LS420, P712, Z760 Aiptek A-HD, A-HD+	KLIC-5000, NP-60



Rechargeable NiMH AA / AAA Batteries

Duracell Part #	Description
DC1500B4N	DURACELL® AA 2650mAh NiMH Rechargeable Batteries, 4 pack
DC2400B4N	DURACELL® AAA 1000mAh NiMH Rechargeable Batteries, 4 pack



Rechargeable Digital Camera Battery Chargers

Duracell Part #	Description	Fits Models
DRCHDIG	DURACELL® Universal Digital Camera Battery Charger	Canon, Fuji, Kodak, Konica Minolta, Nikon, Olympus, Panasonic, Sony
DRCHDIG1	DURACELL® Digital Camera Battery Charger with one plate	Canon, Panasonic, Sony
DRCHDIG2	DURACELL® Digital Camera Battery Charger with one plate	Canon, Fuji, Nikon, Olympus
DRCHDIG3	DURACELL® Digital Camera Battery Charger with one plate	Canon, Nikon
DRCHDIG4	DURACELL® Digital Camera Battery Charger with one plate	Casio, Konica Minolta, Panasonic
DRCHDIG5	DURACELL® Digital Camera Battery Charger with one plate	Fuji, Nikon
DRCHDIG6	DURACELL® Digital Camera Battery Charger with one plate	Kodak

Available exclusively from

Battery-Biz® Inc.

www.Battery-Biz.com

1380 Flynn Road
Camarillo, CA 93012, USA
info@battery-biz.com

Phone: 800.848.6782
International: 805.437.7777
Fax: 805.437.7722